


The **ONE AND TWO** collection

ONE AND TWO OPENWORKED

How to use your watch



WATCH SETTING

TWO-position crown

- 1. Neutral and winding position**
Allows the user to manually wind their watch by turning the crown upwards.
- 2. Time setting position**
Allows the user to set the time by turning the crown and turning the hands to the right time.



SPEAKE-MARIN

CAUTION

Every time you change the time, remember to put the crown back in position 1.

WARNING

Your watch is guaranteed water-resistant to 3 bars (30 m) provided the crown is placed back in position 1.